



Installation Instructions

Viper Rocker Protective Decals

Clear protective decals for 1992 thru 1995 Viper RT/10 side exhaust rocker panels. Electronically die-cut to shape, 3M pressure-sensitive vinyl films. Set includes three for driver side and three for passenger side.

VPR-7008 --- Rocker Panel Protective Decal Set

Materials Needed for Application:

- Application Squeegee (Included with kit)
 - X-acto Knife or similar.
 - Soft Cotton Towel (Lint-Free)
 - Wax and grease remover
 - Spray Bottle - 16 oz. misting bottle is ideal. Add two drops of Joy liquid dish soap and fill with warm water.
1. Clean all surfaces with soft cotton towel and 3M wax and grease remover or similar.
 2. Using the X-acto knife, carefully remove the clear protective rocker decal from its liner to expose the adhesive side.
 3. Spray the entire decal and application area on the vehicle using the mixture of water /Joy solution.
 4. Apply the decal onto vehicle surface. Align by sliding into place and burnish water/joy solution from under. Work from the top down with even strokes and coverage. Caution should be used as the decals are fragile when wet.
 5. Once completely burnished, slowly remove the paper mask covering to reveal the clear protective finish.
 6. If water/joy solution remains, carefully re-burnish to release. Heat may be applied using a hair-dryer or heat gun to help cure. Do not overheat.
 7. For best results, allow decals to set overnight.

Got Questions? Ask The Pro's We are pleased to help you with the installation process. Just give us a call and we can guide you through the installation.

1-800-872-4614